

Operating instructions for the Automatic 24/7 Dispenser

Basic Function

The unit will spray every 15 minutes and operate for a full 3,000-spray cycle.

LED Indicator Lights

During normal operation, Green LED blinks approximately every 5 seconds. Red LED blinks indicate that it is time to replace the can. No blinking LED light indicates the need to replace the batteries. The LED indicator will not be lit when in the OFF position.

Operation

If the aerosol can cannot be inserted because the actuator arm is down, gently push the actuator arm upward to allow the nozzle to fit properly below the actuator arm. Make sure the can is firmly positioned in the bracket and that the nozzle tip is pointed away from the unit. The aerosol can may not always spray on the first cycle. Allow several cycles to be sure the can is spraying properly, or press the OFF button, then ON. The LED indicator will blink red and green three times and then spray.

Place Can in Dispenser

Make sure tip is facing forward. Shoulder of can should be resting on retainer bracket. Reset by pressing the ON/OFF each time you change batteries or replace cans. The led indicator will flash green / red 3 times and the activated arm will activate 1 time as a system check.

Caution

Always use caution and face away from the unit while turning OFF and ON — and while installing or removing a can from the unit.



AutoScents Auto Aerosol Dispenser 24/7 #104699

****Dispenser operates off 2 D batteries